



White Paper

Title: Using Lambda to determine Air/Fuel Ratio

TSN Number: 10

File:\\MII-

SRV1\Metron\Bridge_Analyzers\Customer_Service_Documentation\White_Papers\10
Lamda A-F No Formula.docx

Created by: R. Schrader

Last Revision Date: 03-Nov-03

The Bridge Model 9004 (4-Gas) and Model 9005 (5-Gas) analyzers calculate the Oxygen/Combustibles balance (λ - Lambda) from the measured values of O₂, CO, CO₂, unburned HC, and NO_x (for the Model 9005) in the exhaust gas. This is a direct measurement of Air/Fuel ratio, and may be easily used to assess fuel mixture balance.

The lambda calculation compares all of the oxygen in the exhaust gases to all of the carbon and hydrogen in the gases. (Water, which contains both hydrogen and oxygen, is determined by estimation using the fraction of the sum of CO to CO₂ in the exhaust.)

The result of the calculation is the 'Lambda' (λ) a dimensionless term that relates nicely to the stoichiometric value of air to fuel. At the stoichiometric point, Lambda = 1.000. A Lambda value of 1.050 is 5.0% lean, and a Lambda value of 0.950 is 5.0% rich. Once Lambda is calculated, A/F ratio can be easily determined by simply multiplying Lambda times the stoichiometric A/F ratio for the fuel used - e.g. 14.71 for gasoline, 15.87 for LPG, and 17.45 for CNG.

Details of the Lambda Calculation:

Although this calculation is complex, it is easy to use in practice. Lambda directly reflects the 'degree of lean-ness' of the air/fuel mixture – **and is independent how efficiently the fuel is oxidized** – a very important factor to consider when dealing specifically with air / fuel balance issues. The manner in which this equation is to be used is strictly a function of the application though, and it is an excellent replacement for more commonly used conventions, such as CO measurement for rich-side applications (performance tuning), 'wide range lambda sensors', which are not only very non-linear, but also very sensitive to combustibles in the exhaust stream, or EGT, which is a combination of flame temperature and volume (power).

The only dependable air/fuel ratio measurement that we have found to date is one that first makes an accurate measure of the constituent gases in the exhaust stream (at least the four gases of HC, CO, CO₂ and O₂) and calculates the oxygen and combustibles content and then the lambda and A/F value as above.

Bridge Analyzers, Inc.
PO Box 39325
Solon, Ohio 44139 USA

(510) 337-1605 office
(216) 274-9262 fax
support@bridgeanalyzers.com



White Paper

The Relationship between Lambda and A/F ratio:

Because $\Lambda = 1.000$ when the oxygen and combustibles are in perfect stoichiometric balance, Lambda can easily be used to calculate A/F ratio for particular fuels.

The active A/F ratio is simply the calculated Lambda times the stoichiometric A/F ratio for the specific fuel used (14.71 for gasoline, but other fuels have different values) This method is far superior to other approaches which use only one gas (CO or Oxygen) to approximate A/F ratio – as this method uses all of the oxygen and carbon-bearing gases to calculate the ratio of air to fuel.

We have found that providing a uniform method to relate the specific exhaust gas constituents to air/fuel balance (independent of the quality of the combustion process or the power produced) makes the engine tuner's job much easier – and easier to understand as well.

The effect of various 'octane' fuel mixes on Lambda:

Various mixes of gasoline contain differing ratios of short and long hydrocarbon chains, resulting in a variation of octane rated fuels. This has a small effect on the ratio of hydrogen to carbon in the fuel, but these variations have a trivial effect on the lambda calculation.

The effect of Oxygenated fuels on Lambda:

Oxygenated fuels contain a very small amount of oxygen in the fuel, which is released as the fuel is burned. The total O₂ equivalence in typical oxygenated fuel is on the order of 0.1% O₂, so this effect is very small.

The effect of NO_x on Lambda:

NO has a relatively immaterial effect on the lambda calculation, as 1,000 ppm NO is only equivalent to 0.05% Oxygen utilization. A 4-gas analyzer is adequate for lambda calculation - **but at least 4 gases must be measured.**

Sample Dilution and Air Injection Effects on Lambda:

As a side note, it is important to understand the effect that sampling air leaks or outright air injection may have on lambda calculation. **The percentage of extra air in the exhaust gases will result in the same percentage error in the Lambda calculation.**

I.E, a 5% air leak will not only dilute (lower) the CO, HC, CO₂ and NO_x gas readings by 5%, but will increase the Oxygen reading by about 1.00% (5% of 20.9%) and will result

Bridge Analyzers, Inc.
PO Box 39325
Solon, Ohio 44139 USA

(510) 337-1605 office
(216) 274-9262 fax
support@bridgeanalyzers.com



White Paper

in the calculated Lambda being 5% leaner than it should. That means that a perfect Lambda of 1.000 will be reported as 1.050 if there is 5% air leak or injection.

This is a significant error, and can occur relatively easily. It should be noted that air leaks or injection will always bias the lambda calculation toward the lean side – so they should be dealt with and corrected before any lambda calculations using measured gases are attempted.

Air injection should be disabled for Lambda to be calculated correctly.

Engine Misfire – the effect of Combustion Efficiency on Lambda:

Because the Lambda calculation determines the balance between Oxygen and combustible gases by comparing all the oxygen available to the combustibles bearing gases – it is relatively insensitive to the degree to which the combustibles have been oxidized. Thus, an engine misfire has absolutely no effect on the balance calculation.

In essence, because all of the gases are used in the lambda calculation, the gas mix in the intake manifold, half-way through the combustion process, before a catalytic converter, or at the tailpipe will ALL yield the same Lambda result. The intake manifold will contain Oxygen, HC, and no CO, CO₂, or NO_x. They will, however be in balance. The tailpipe should contain low levels of Oxygen and HC and CO (the sources of combustion), but high levels of CO₂ and water vapor. They will be at the same balance as the intake manifold gases. It really does not matter where the gases are measured, or how efficient the combustion process is operating.

Pre and Post Catalytic Converter gases:

Because the Lambda calculation determines the balance between Oxygen and combustible gases by comparing all the oxygen available to the combustibles bearing gases – it is relatively insensitive to the degree to which the combustibles have been oxidized. Thus, the gas stream before a catalytic converter should calculate the same Lambda value as the gases after a catalytic converter.

Bridge Analyzers, Inc.
PO Box 39325
Solon, Ohio 44139 USA

(510) 337-1605 office
(216) 274-9262 fax
support@bridgeanalyzers.com